# Protective and working scaffold

# Instructions for assembly and use







July 2008, english Keep for later use!



# 1.0 Table of Contents

2.0	Product features / Safety instructions	
	2.1 General information	3
	2.2 Safety instructions	3
3.0	Components	4-9
4.0	Assembly and dismantling	10
5.0	Corner formation	11-12
6.0	Length compensation	13
7.0	Strut extension	14
8.0	KG Lower platform	15
9.0	Bridging of openings	16
10.0	Height offset of suspension	16
11.0	Application as safety scaffold	17-18
12.0	Application as working scaffold	19-20
13.0	Anchoring	21-22



# 2.0 Product features

The Hünnebeck folding scaffold is collapsible and ready for use immediately on the building site, 1.80 m wide formwork units, which can be employed as working and protective formwork in accordance with EN12810/11. The system comprises sections in the lengths of 3.0 m and 4.5 m, as well as the corner folding scaffold for the standard corner formation.

In addition there is an extensive range of accessories, for example KG Lower platforms, strut and railing extensions available. The folding scaffold consists of collapsible sections, their integrated bracings and suspensions as well as the facing with side protection. The scaffold cover is composed of 5 cm thick, edgeprotected planks. Posts and side protection bars are manufactured from square tubing, supplemented by a toe board. All steel parts are galvanised and the wood is specially treated in accordance with DIN 68800. This guarantees both a long service life and a high standard of safety.

### 2.1 General information

In this erection and applicational manual you will find essential information concerning the erection and application of the folding scaffold from Hünnebeck, together with the precautionary measures that are necessary for safe installation and application. These instructions are intended for the effective work with the folding scaffold. Please read the manual carefully prior to erection and use of the folding scaffold and keep it handy as reference material.



Cautionary notes and warnings are identified in this erection and usage instruction as . Non-observance with these notes may lead to severe injuries and/or damages!

### Legend:



# Warning/Caution!:

refers to erection steps, which must be followed very carefully, otherwise the proper installation of the folding scaffold cannot be ensured.

Non-observance may lead to severe injuries and/or damages. These warnings and notes require absolute attention in order to ensure the desired safety provided by the folding scaffold.

# Inspection:

refers to erection steps which require specific attention by either visual inspection or other means described in more detail.

# 2.2 Safety Instructions

The following erection and use instructions contain information regarding the handling, installation and use of the products mentioned or depicted in it.

The illustrations shown in these standard erection and use instructions shall be considered as samples only on how to use "the folding scaffold" safely. Add-ons, deviations or changes to specific items always require additional installation instructions by the user, which must be provided based upon the assessment of the risk and, if necessary, requires additional structural analysis.

The currently available occupational health and safety regulations always apply to the safety-related use of our products.

The assembly must always be carried out when the fall protection is still effective. In other cases suitable safety measures in compliance with § 5 ArbSchG (Occupational Safety Directives) must be undertaken by the user.

Only undamaged original parts from the company **Hünnebeck** may be used. For this very reason, all components must be visually inspected for their origin and for possible damage prior to any installation. If necessary, those parts must be replaced with original components.

When requiring spare parts, only original Hünnebeck parts may be used.

Mixing our systems with those from other manufacturers are inherently dangerous and require a separate inspection.

The illustrations in this "erection and application manual" are used to emphasise the recognition of details and therefore, may not always be complete from a safety point of view.

Based on the engineering development, we reserve the right to change any design without prior notice.

The latest issue of the erection and application instructions may be downloaded from the internet, go to www.huennebeck.de or they can be ordered from Hünnebeck directly.

# 3.0 Components

	Description	Item No.	Weight kg/unit
Basic elements  296	Folding scaffold 300 Completely assembled scaffold units consisting of 2 collapsible brackets, their bracings, the impregnated and edge-protected board platform, as well as the guardrails made of square tubing with a wooden toe board.  The guardrail is lockable at two points and can be collapsed for transport purposes. The folding scaffold is equipped with lowable crane stirrups.	490 005	283.30
446	Folding scaffold 450 as described above, but with 3 brackets.	490 016	419.10
248 372	Corner folding scaffold R (= Right) Pre-assembled scaffolding unit as described above, equipped with 2 brackets and an extended and reinforced punch guide on one side. The Corner folding scaffold R together with the Corner folding scaffold L forms the system solution for corners maintaining the entire width of the platform even in corner areas due to the shapes of these projecting parts. At the same time 5 meters of wall are scaffolded.	533 745	346.00
248	Corner folding scaffold L (= Left) as described above.  Important note! Corner folding scaffold R + L for the consolution provide only in pairs. The Corner folding scaffold can also be used on wall areas. (See Page 11).	533 756	346.00

	Description	Item No.	Weight kg/unit
8,5	Bracket bearing is anchored to the building and serves as a suspension for the brackets of the folding scaffold. Unintentional unhinging is eliminated by the securing with the safety bolt.	463 010	3.60
26	KG Corner connection In the corner region this part is pushed onto the guardrail tubing of the scaffold and secured with respectively one Waler bolt D20 + spring pin. The KG Corner rail of the scaffold are guided through the hooks of the KG Corner connections (4 pcs. per corner).	498 229	1.60
275	KG Corner rail The gap in the corner region is closed with KG corner rails which are pushed into place (2 for each corner, wall and knee rail). The KG Corner rail is secured against falling out of place by a Waler bolt D20 + spring pin.	498 230	9.10
2.5 × 0 × 0 × 0 × 0 × 0 × 0 × 0 × 0 × 0 ×	Waler bolt D20	420 000	0.30
0,4 Ø	Spring pin secures the coupling of the KG Corner connection, the KG Corner rail and the KG Rail extension.	173 776	0.01
75	KG Corner toe board closes the toe board gap on the Corner folding scaffold R + L. It is simply inserted into the retaining holes of the cover.	534 202	3.50

# 3.0 Components

	Description	Item No.	Weight kg/unit
Supplementary equipment	KG Rail extension The guardrail compensations in the region of the wall are shored by the KG Rail extensions. Unilaterally pushed into place on the guardrail tubing of the adjacent scaffolding units and secured with respectively one Waler bolt D20 + spring pin in the perforated strip. Adjustment up to 50 cm = 2 pcs. Adjustment between 50 and 100 cm = 4 pcs.	498 218	3.60
150	KG Rail transversal  An entire guardrail unit that is clamped to the edge of the planking of the scaffolding unit, e.g. as a KG Rail transversal at the ends of scaffolds, which are not equipped with surrounding platforms.	498 115	23.70
215	KG Corner plank Bridges the platform planking if scaffold corner units are not employed, but the Folding scaffolds 300 + 450 are being used. The planking is equipped with toe board, edge protection, crane hoops and fixing plates for securing purposes.	498 446	69,40
289	KG Suspension bar The vertical section of the brackets in the Folding scaffold is extended with the KG Suspension bar. It is connected with respectively 2 bolts 105 + spring pin and is able to support both the KG Bearer bar and KG bearer, but also the KG Lower platform.	526 330	26.00
	KG Bearer bar With the use of the KG Bearer bar in connection with the KG Suspension bar a lower supporting point on the building can be located for the folding scaffold (e.g. in the case of open facades). Two must be provided for each KG Bearer bar.	530 259	23.30

	Description	Item No.	Weight kg/unit
452	KG Bearer Using one Bolt 105 + spring pin the KG Bearer can be fixed in the perforated strip of the KG Suspension bar at the required height for the supporting point.	530 215	5.70
143	Folding scaffold horizontal As a horizontal bracing this tube is mounted at the lower connection point of the KG Bearer bar with respectively 2 Bolts M 20 x 40 + nut 4.6.	490 200	2.40
A A	Bolt M 20 x 40 + nut 4.6  Fixes the Folding scaffold horizontal with the KG Bearer bar.	001 300	0.20
296	KG Lower platform 300 By means of the KG Lower platform the folding scaffold is furnished with a supplementary working level. Reworking on the facade can be performed from this platform. The board platform and railings are executed as per the folding scaffold. The platform bearers located axis of the brackets enable the coupling to the KG Suspension bar with 4 bolts 105 + spring pin in the KG Lower platform 300 (6 bolts 105 + spring pin in the KG Lower platform 450).	526 569	157.60
446	KG Lower platform 450 See above.	526 570	238,20

# 3.0 Components


	Description	Item No.	Weight kg/unit
10,5	Bolt 105 + spring pin Connector for KG Suspension bar, KG bearer and KG Lower platform.	154 127	0.29
23,5	KG Connector enables the connection of a formwork diagonal strut as well as a wind tension strip. It is secured in the platform of the folding scaffold with a Waler bolt D20 + spring pin.	536 109	0.78
21 26 22,2 Ø	KG Hook replaces the installed suspension when the anchoring of the formwork is to be accomplished through reinforcement loops.	526 190	5.60
107	KG Single post Whenever special lengths in the railing are required the KG Single post is equipped with board rails on site.	490 678	5.10
190	<ul> <li>KG Single bracket</li> <li>employed for the production of folding</li> <li>scaffolds in special lengths. The planking* and the rail planking* are created and mounted on site.</li> <li>* Dimensioning of the timber parts in compliance with static requirements.</li> </ul>	529 573	59.60

	Description	Item No.	Weight kg/unit
Anchoring parts	Tie cone M 24/D+W The Tie cone M 24/D+W is equipped with a M24 thread at the front for the mounting of the bracket bearing. The lost rear anchor parts are retained at the rear in the D+W screw thread. The cone is removed from the concrete using a Turnscrew w.a.f. 24.	496 664	0.65
25	Turnscrew w.a.f. 24 to remove the cones from the concrete.	542 471	1.25
7	Fit bolt M 24x70 5.6 for the mounting of the bracket bearing to the tie cone M 24/D+W (ratchet with extension and the 24 nut for the mounting process).	185 635	0.47
107	Nailable disk M24 Fixes the tie cone M 24/D+W to the wall formwork (Turnscrew w.a.f. 12 for assembly and installation).	515 947	0.16
60	Pigtail anchor 60 Lost rear anchor. Is embedded into the concrete with screwed tie cone M 24/D+W.	509 581	1.00
Office of the state of the stat	Tie rod DW15 per meter run  Lost rear anchor. Is cut to length on the building site and embedded into the concrete together with the screwed-on tension nut and the cone.  Observe the installation instructions!	164 811	1.00
10	Tension nut serves as a locking plate (40 kN admissible load).	197 332	0.65

# 4.0 Assembly and dismantling

# **Delivery situation**


Wooden pads 15 x 15 x 70 cm



# **Erection:**


**1.** Position the railings, elevate and allow them to lock into place as required (straight or inclined).

Remove the crane loops and connect a four-fold hanger.




**2.** Remove the bolts (1) for the shipping lock and the bolts (2) securing the diagonal tubing.

Then remove the diagonal tube from the vertical strut of the platform of the folding scaffold.




**3.** Lift the folding scaffold ca. 2 m with the crane and secure the diagonals with the bolts (1 + 2).

The folding scaffold is now ready for use.




Securing the diagonal tube:



The folding scaffold is folded together once again in reverse sequence.



# Corner formation with corner folding scaffolds



The formation of a corner scaffold is accomplished with the **Corner folding scaffolds R** and **L**, which are always used pairwise.


The entire platform width of 180 cm is maintained by the use of these scaffold units.

The railings are locked by means of the insertion and fixation of the **KG Corner rails** into the hooks of the **KG Corner connection**. Location holes are provided in the planking for the **KG Corner toe board**. The positioning of the railings can be freely selected (vertical or externally inclined).


# Ground plan corner (Dimensions in cm)

### Use in wall areas

The **Corner folding scaffolds R** and **L** can be employed in wall areas. The gap arising due to the form of the formwork unit is covered with planks, min. 24/4.5 cm. The railings must be locked by **KG Rail extensions** (see page 13).



# 5.0 Corner formation




On application within the scaffold groups ranging from 1 to 4 it is possible to execute the corner transition without standard **Corner folding scaffolding**. The gap arising in the corner transition will be covered with the **KG Corner planks**. These are secured against displacement by nails following the positioning

on the folding scaffold.

In the standard corner design the railing is locked and closed with **KG Corner connections** and **KG Corner rails**.

The KG Toe board is integrated in the KG Corner plank.



# 6.0 Length compensation


# H Folding Scaffold

On application as a safety scaffold the

Important note!

(Dimensions in cm)

Length compensation with facing cover



guidelines specified on page 17 must be adhered to!

KG Rail extension
Waler bolt D20
+ sprin pin

50-100

On application of the folding scaffolds gaps could occur during the length adjustment, which must be bridged by a plank. Hence planks with dimensions of at least 24/4.5 cm are necessary (toe board 15/3 cm). The length is calculated from the plank gap + 2 x min. 75 cm bearing length.

The planks must be secured against displacement by appropriate measures.

The gap in the railing is closed with the **KG Rail extension**. On one side (on two sides in the case of adjustments from 50 to 100 cm) it is pushed onto the railing posts of the adjacent scaffold units and secured respectively with one **Waler bolt D20** + **sprin pin**.

Observe the maximum compensation width for the arising load condition!


### KG Rail transversals at the end of the scaffold

The **KG Rail transversal of the folding scaffold** is a guardrail unit 150 cm long, which is clamped to the edge of the plank of the folding scaffold.


Possible use would be, for example, at the ends of the scaffolding, (when the platform does not surround the building completely) as well as in inside corners of buildings. In this case the standard guardrails are removed and replaced by the **KG Rail transversal** of the folding scaffold in order to maintain the necessary passageway.

It must be ensured that the scaffolding is not loaded diagonally to the longitudinal axis by the weight of the formwork. Hence in application of the formwork, brackets (e.g. **Climbing brackets 1** Art. No.: 021 692) must be provided.

The length of the **KG Rail transversal** can be extended up to 250 cm.



# 7.0 Strut extension





By reason of the application of a strut extension the **folding scaffold** can also be employed on buildings with frame construction or in regions with extensive openings in walls. The bearing point of the scaffold is then variable and can be maximum 400 cm below the scaffold level. In this structural design the **folding scaffold** in scaffold group 3 in accordance with DIN 4420 Part 1 (with or without formwork) can be employed.

### Assembly and mounting sequence:

- Lift the folding scaffold unit A with the help of a crane (see Page 10).
- Mount the diagonal tube B and KG Bearer bar C to the horizontal bracket bearer A1 (with respectively one bolt 1 + 2).
- 3. Fix the KG Suspension bar D to the vertical bracket bearer A2 using two bolts. The diagonal tube B is also held in position by one of these bolts.
- Now the KG Bearer bar C is connected with the KG Suspension bar D with one bolt (1) and the KG Bearer E is brought into the required position.
- For reinforcement the horizontal F is mounted using 2 Bolt M20x40 + nut 4.6.

Strut extension comprising:		Number of pieces for	
Description	Art. No.:	KG 300	KG 450
KG Suspension bar	526 330	2	3
KG Bearer bar	530 259	2	3
KG Bearer	530 215	2	3
Folding scaffold horizontal	490 200	1	2
Bolt 105 + spring pin	154 127	10	15
Bolt M20x40 + nut 4.6	011 300	2	4







The application of KG Lower platforms creates a supplementary lower working level. The clearance to the top scaffold platform is adjustable (20-cm grid) and amounts to max. 400 cm. From the KG Lower platform, predominantly when formwork is used, different work such as the dismantling of suspension parts, the mounting of necessary wind protections as well as reworking on the facade can be performed. The KG Lower platform has a load bearing capacity in compliance with the scaffold group 2 defined in DIN 4420 part 1.


KG Lower platform comprising:		Number of pieces for	
Description	Art. No.:	KG 300	KG 450
KG Lower platform 300	526 569	1	-
KG Lower platform 450	526 570	-	1
KG Suspension bar	526 330	2	3
Bolt 105 + spring pin	154 127	8	12

### Assembly and mounting sequence:


- The KG Lower platform B is positioned on trestles using the crane. This auxiliary construction from building site materials is required when the platform clearance should be ≤ 380 cm.
- 2. When the railing is unfolded, the KG Suspension bar C is guided through the holes located in the bracket axis and fixed at the required height using 2 bolts 1. (Observe the correct position of the KG Suspension bar C).
- 3. The folding scaffold unit A is erected as described on Page 10 and guided over the KG Lower platform hanging in the cable of the crane. The diagonal tube A1 is not connected at the bottom during this process. The crane lowers the platform so far that the vertical bracket girder A2 can be connected in the hinge of the KG Suspension bar C with 2 bolts 1.
  At the same time the diagonal tube A1 is mounted.









# 9.0 Bridging of openings






Bridge girder	Possible opening width in application as working scaffold + service scaffold			
Square shaped				
timber 12/14 cm	1.40 m 1.00 m			
Cam waler	4.00 m 3.00 m			
Scaffold group	up to SG 3 up to SG			

GG = scaffold group in accordance with DIN 4420 Part 1



# 10.0 height offset of the suspension



# 11.0 Application as protection scaffold



The **folding scaffold is** applicable as a protection scaffold in accordance with DIN 4420 Part 1 classification scaffold group 3 (area related effective weight 200 kg/m²).

The standard suspension as well as the loop hook can be employed in this case.


The maximum compensation between the **scaffold units** amounts to 1.0 m.

A height offset in the suspension of up to 50 cm is permissible. All particulars with regard to the use as a protection or working scaffold are relevant for a height of 100 m above the ground (excluding the region of the German Bight as well as locations that are more than 1200 m above sea level).

Detail: Length compensation

Ground plan:

(Dimensions in cm)




\*= the actual dimensions of the offset is always 4 cm larger than the specified system dimensions.

Planking bridge for application of safety scaffold: up to a gap of 50 cm in the facing: 1 bearing plank  $24 \times 5$  cm.

# 1. Folding scaffold as safety scaffold in accordance with DIN 4420 Part 1


Use in normal position (without height offset)

Application with height offset of 50 cm




# 11.0 Application as safety scaffold

# 2. Folding scaffold as protective canopy in accordance with DIN 4420 Part 1



If the **folding scaffold** is used as a protective canopy, a board panel at least 60 cm high must be created by the insertion of planks measuring 15/4.5 cm into the guardrails. The planks are secured by means of strap joints arranged next to each post. The free space between the scaffold and the masonry must be covered with planks.



# 3. Folding scaffold as safety roof scaffold in accordance with DIN 4420 Part 1





Diagram for the determination of the maximum height position of the facing dependent on the depth of the eaves.



Example for the determination of the maximum dimension "H". (Clearance eave depth - facing).

Eave depth dimension  $_{,,}$ A" = 0.4 m Resulting dimension  $_{,,}$ H" = 0.9 m


# 12.0 Application as working scaffold



The <u>folding scaffold</u> can be employed both as working scaffolds <u>without formwork</u> with high live loads (e.g due to reinforcement) as well as <u>with formwork</u> at reduced life load (without material lining).

### Overview:


- 1. Working scaffold without formwork.
- 2. Working scaffold with formwork supported on floor structure (inside building).
- Working scaffold with formwork supported on folding scaffold.



Opportunities for application in the classified scaffold groups 3 to 6						
Scaffold group:	3		4	5	6	
Area related effective load	200 kg/m²		300 kg/m <sup>2</sup>	450 kg/m²	600 kg/m²	
Load due to formwork:	with		without			
max. height offset to starting position:		50 cm*	35 cm	20 cm		
Corner formation with corner folding scaffolds R + L:	applicable					
Corner formation with covering according to Page 12	applicable	applicable	applicable			
Length compensation:	100 cm:	100 cm:	100 cm:	100 cm:	50 cm	
KG Lower platform	applicable	applicable				
Strut extension:	applicable:	applicable				
Loop hooks		applicable				


<sup>\*=</sup> If loop hooks are employed a maximum height offset of ≤ 25 cm is admissible. A height offset of up to maximum 50 cm is enabled by restricting the length compensation to ≤ 40 cm.

In the case of a concentric support by means of a KG Single bracket length compensations of 1.50 cm are fundamentally possible.



# 12.0 Application as working scaffold

# 2. Working scaffold with formwork supported on floor structure.



**Folding scaffold:** scaffold group 3 in accordance with DIN 4420 (area-related effective load: 200 kg/m²).

Wall formwork up to a maximum height of 5.40 m. Pouring platform: scaffold group 1 (75 kg/m²).

KG Lower platform may be employed. Scaffold group 2  $(150 \text{ kg/m}^2)$ .

Facing bridging maximum 1.00 m.


No height offset in the suspension permitted.



### Important note:

When the height of the formwork exceeds 3.00 m a protection against falling is necessary (2 pouring platforms)!

# 3. Working scaffold with formwork supported by folding scaffold.



**Folding scaffold:** Scaffold group 3 in accordance with DIN 4420 (area related effective load: 200 kg/m²).

Wall formwork up to a max. height of 5.40 m. Concrete casting platform: scaffold group 1 (75 kg/m²).

KG Lower platform may be employed. Scaffold group 2 (150 kg/m²).

Facing bridging maximum 1.00 m.


No height offset in the suspension permitted.

in the case of wind velocity up to 15 m/s (crane operation must be ceased in the case of such wind speed in storms).



# Important note:


The formwork must be tightly connected to the floor ceiling and pressure resistant in the case of: wind velocity exceeding 15 m/s in case of each shut-down time and prolonged interruptions in work.




# 13.0 Anchoring

# H Folding Scaffold

# 1a. Creation of the anchor pointwith pigtail anchor



### 1b. - with tie rod and tension nut




### 2. Mounting the bracket bearing

After the removal of the formwork the bracket bearing is mounted to the anchor point with the fit bolt M  $24 \times 70$ .

A ratchet with an extension and a 24 socket are suitable for this purpose.

Fit bolt M 24x70 5.6



# 3. Hook in of the folding scaffold

When the strength of the concrete at the anchor point corresponds to B 15, the folding scaffold is suspended into the bracket bearing with the crane. The scaffold must then be protected against lifting by the use of safety bolts (mounted to brackets).


The following loads could arise at the anchor point due to the cases in operation defined in this erection manual:

max. horizontal load: 16 kN max. vertical load: 21 kN

With Corner folding scaffold R/L H = 22 kN V = 24 kN


### Remarks:

Evidence must be provided of the bearing capacity of the building and building parts in relation to the specified loads.



# 4. Elimination of the anchor point

The bracket bearing is unscrewed and the tie cone is removed from the concrete using a turnscrew w.a.f. 24.



# 13.0 Anchoring

# Horizontal intervals of the anchoring points

(Arrangement of the anchoring points on the corner of the building see Pages 11 + 12).


### Ground plan:

(Dimensions in cm)

# Supplementary reinforcement on adherence to the minimum clearance

Supplementary reinforcement made of structural steel 500 S Ø 10 mm.

(Dimensions in cm)




The folding scaffold can be anchored to the building using reinforcement loops. For this purpose the standard suspension part must be unscrewed and replaced by a KG Hook.

# Anchoring loop ds ≥ 10 mm BSt 500 S bolt M20 Embedding in 0 the reinforcement KG Hook

ŧ۶

Installation dimension for the anchoring loop (top view):



See table on Page 19 for areas of application.

The following loads could arise at the anchor point:

max. horizontal load: 11.5 kN max. vertical load: 13.0 kN

### Hünnebeck Deutschland GmbH

Rehhecke 80 D-40885 Ratingen Phone: +49 (0) 2102 937-1

Fax: +49 (0) 2102 37651 info\_de@huennebeck.com www.huennebeck.de

The copyright in these instructions for assembly and use belongs to Brand Energy and Infrastructure Services. All the trademarks named in these instructions for assembly and use are the property of Brand Energy and Infrastructure Services, unless marked as thirdparty rights or identifiable as such in another way. Hünnebeck, SGB and Aluma Systems are trademarks of Brand Energy and Infrastructure Services. Furthermore, all rights are reserved, particularly with regard to patent grant or utility model registration. The unauthorized use of these instructions for assembly and use, of the trademarks contained therein and other intellectual property rights is expressly prohibited and represents an infringement of copyright, trademark rights and other industrial property rights. The illustrations in this brochure depict actual site conditions which may not always conform with applicable safety rules and regulations.





